

# Contents

---

List of Figures . . . . .	xi
List of Tables . . . . .	xiii

## Section 1: General Information

About this Manual . . . . .	1
Conventions . . . . .	1-1
Safety Messages . . . . .	
Notes . . . . .	2
References . . . . .	
Worldwide Web Links . . . . .	
Indicators, Switches, and Labels . . . . .	1-2
Locations . . . . .	1-2
Owner Responsibilities . . . . .	1-2
Construction Standards . . . . .	1-3
Deck Layout . . . . .	1-3
Basic Specifications . . . . .	1-6
Boat Information . . . . .	1-6

## Section 2: Safety Information

Purpose . . . . .	2-1
Safety . . . . .	2-1
Suggested Safety Equipment . . . . .	2-2
Flotation Devices . . . . .	2-2
Ropes and Lines . . . . .	2-2
First Aid Kits . . . . .	2-2
Visual Distress Signal (VDS) . . . . .	2-3
Storage . . . . .	2-3
Handling . . . . .	2-3
Disposal . . . . .	2-4
Fuel Safety . . . . .	2-4
Warning Labels . . . . .	2-4
Fire Safety Systems . . . . .	2-6
General Information . . . . .	2-6
Fire Suppression System . . . . .	2-6
Automatic Operation . . . . .	2-6
Manual Operation . . . . .	2-6
After Discharge . . . . .	2-7
Maintenance . . . . .	2-8
Hand-held Fire Extinguishers . . . . .	2-8
Carbon Monoxide Detector . . . . .	2-8

Testing	2-8
Alarm Response	2-9
Flooding or Capsizing	2-9
Minor Flooding	2-9
Hull Leaks	2-9
Raw Water System Leaks	2-9
Emergency Flooding or Capsizing	2-9
Man Overboard	2-10
Preparation	2-10
Plan of Action	2-10
Environmental Safety	2-11
Discharge of Oil	2-11
Garbage and Plastics	2-11
Wastewater Discharge	2-11
Accident Reporting	2-13
Float Plans	2-14

### Section 3: Accommodations

Overview	3-1
Interior Lighting	3-1
Locations	3-1
Power Sources	3-1
Requirements	3-1
Forward Cabin	3-1
Bunks	3-1
Aft Bunk	3-2
Head	3-2
Toilet	3-2
Water Level Monitor	3-3
Receptacle Case	3-4
Shower	3-4
Sink	3-4
Galley Equipment	3-5
Microwave	3-5
Galley Sink	3-5
Galley Icebox	3-5
Storage Cabinets and Drawers	3-6
GFCI Outlets	3-6
Forward Cabin Outlets	3-6
Entertainment Systems	3-7
Shore TV/Phone Connection	3-7
DVD Player	3-7
Plasma TV	3-7
Sound System	3-7
Cabin Climate Control	3-9

Deck Shower ..... 3-9

**Section 4: Pre-Departure**

Overview ..... 4-1

Passenger Boarding ..... 4-1

    Safety Awareness ..... 4-1

    Sea Conditions ..... 4-1

Pre-Departure Checklist ..... 4-2

    Before Boarding ..... 4-2

    Inspect the Fuel System ..... 4-2

    Inspect the Raw Water System ..... 4-2

        Inspect the Seacocks ..... 4-2

        Inspect the Strainers ..... 4-2

    Inspect the Bilge Pump System ..... 4-2

    Inspect the Generator ..... 4-3

        Check Generator Oil ..... 4-3

        Inspect Power System Components ..... 4-3

    Inspect the Batteries ..... 4-3

    Inspect the Engine ..... 4-4

    Inspect Steering Control ..... 4-4

    Disconnect Power ..... 4-4

    Start the Engine ..... 4-4

    Start the Engines ..... 4-4

    Engine Power ..... 4-5

    Engine Shutdown ..... 4-5

**Section 5: Helm Instruments and Controls**

Overview ..... 5-1

    Instrumentation ..... 5-1

        Range ..... 5-1

        Analog Meters ..... 5-1

        Speedometer ..... 5-1

        Navigation System ..... 5-2

        Compass ..... 5-2

        VesselView ..... 5-2

    Controls ..... 5-2

        Engine Run/Kill Switch ..... 5-3

        Engine Ignition Switches ..... 5-4

        Steering ..... 5-4

        Throttle Controller ..... 5-4

        Engine Trim Controller ..... 5-5

        Trim Tab Controls ..... 5-5

        Bow Thruster Controller ..... 5-5

        Communications ..... 5-6

        DC Distribution Switches ..... 5-6

Port DC Distribution Panel . . . . .	5-6
Starboard DC Distribution Panel . . . . .	5-7
Autopilot . . . . .	5-7

## Section 6: Anchoring, Docking, and Mooring

Purpose . . . . .	6-1
Attachment Points . . . . .	6-1
Docking and Mooring . . . . .	6-2
Mooring Line Specifications . . . . .	6-2
Securing Alongside . . . . .	6-3
Securing in a Slip . . . . .	6-3
Anchoring . . . . .	6-4
Windlass . . . . .	6-4
Motor Controller . . . . .	6-4
Power Source . . . . .	6-4
Fresh Water Washdown . . . . .	6-5

## Section 7: Post-Voyage

Overview . . . . .	7-1
Post-Voyage Checklist . . . . .	7-1
Shut Down Engines . . . . .	7-1
Secure the Cabin . . . . .	7-1
Inspect the Interior . . . . .	7-1
Empty Bilge Water . . . . .	7-1
Close the Hatch . . . . .	7-2
Shut Down the Generator . . . . .	7-2
Turn off Power Sharing . . . . .	7-2
Inspect Raw Water Systems . . . . .	7-2
Inspect the Engines . . . . .	7-2
Inspect the Generator . . . . .	7-3
Isolate Cranking Batteries . . . . .	7-3
Inspect All Batteries . . . . .	7-3
Inspect Steering/Handling Components . . . . .	7-3
Shore Service — Head Waste . . . . .	7-3
Clean the Exterior . . . . .	7-4
Clean Exterior Upholstery . . . . .	7-4
Clean the Interior . . . . .	7-4
Clean the Sump Box . . . . .	7-4
Disconnect Shore Water . . . . .	7-4
Inspect Shore Power . . . . .	7-4
Remove Trash and Wet Gear . . . . .	7-4
Inspect Helm Distribution Panels . . . . .	7-4
Inspect the Galley Electrical Panels . . . . .	7-4
Close Hatches and Cabinets . . . . .	7-5

## Section 8: Propulsion System

Overview	8-1
Engines	8-1
Fuel System	8-2
Air Intake	8-2
Oil System	8-2
Cooling System	8-2
Alternators	8-2
Exhaust	8-2
Propellers	8-2

## Section 9: Steering and Handling Systems

Overview	9-1
Main Steering System	9-1
Steering Helm	9-2
Autopilot Pump	9-2
Power Steering Pump	9-2
Steering Piston	9-3
Tie Rod	9-3
Bow Thruster System	9-4
Trim Tabs System	9-6
Trim Tabs	9-6
Fuel and Reservoir	9-6
Engine Control	9-7

## Section 10: Fuel System

Overview	10-1
Gasoline Fuel (Gasoline)	10-2
Requirements	10-2
Fuel Storage Tank	10-3
Fuel Vent	10-3
Fuel Lines	10-3
Fuel Filters	10-3
Gasoline Fueling Instructions	10-3
Generator Fuel (Diesel)	10-4
Diesel Fuel Lines and Filters	10-5
Diesel Fuel Filter	10-6
Diesel Filling Instructions	10-6

## Section 11: Electrical System

Overview	11-1
AC Power Sources	11-2
Generator System	11-2
Fuel Source	11-3

Controls	11-3
Auto-Shutdown	11-3
Cooling System	11-4
Exhaust	11-4
Engine Starting	11-4
Shore Power System	11-5
Connecting to Shore Power	11-5
Disconnecting Shore Power	11-5
Engine Alternators	11-7
Charger/Inverter	11-7
Power Sharing Controller	11-7
Windlass/Bow Thruster Battery Charger	11-7
Batteries	11-10
Cranking Batteries	11-10
House Batteries	11-10
Windlass/Bow Thruster P	11-11
Generator Cranking P	11-11
Battery Isolators	11-11
Battery Paralleling	11-11
Cranking Battery Switc	11-12
12-Volt DC Distribution	11-12
12VDC Circuit Breaker Panel	11-13
120-Volt AC Distribution	11-19
120V/60Hz Distribution Panel	11-19
240-Volt AC Distribution	11-22
240VAC Distribution Panel	11-22
AC Outlets	11-24
120VAC Outlets	11-24
20VAC GFCI Outlets	11-24
Corrosion Control	11-25
Fuses	11-25

## 12.00 Fresh Water Systems

Overview	12-1
Shore Water Connection	12-1
Components	12-1
Connecting to Shore Water	12-2
Storage and Distribution	12-2
Fresh Water Tank Fill	12-2
Storage Tank	12-3
Fresh Water Pump	12-3
Water Filter	12-4
Distribution	12-5

Water Manifold .....	12-5
Cold Water Distribution .....	12-6
Hot Water Distribution .....	12-6
Water Heater .....	12-6
Temperature Control .....	12-7
Maintenance .....	12-7

## Section 13: Raw Water System

Overview .....	13-1
Livewell and Generator Raw Water .....	13-1
Seacock .....	13-1
Strainer .....	13-1
Raw Water Pump .....	13-1
Drainage .....	13-1

## Section 14: Wastewater and Drainage

Overview .....	14-1
Bilge Water Systems .....	14-1
Operation .....	14-1
Components .....	14-2
Bilge Pump .....	14-2
Bilge Valve .....	14-2
Bilge Pump Switch .....	14-3
Bilge Pump Alarm .....	14-3
Grease Interceptor .....	14-3
Drain Pipes .....	14-3
Sump .....	14-4
Grey Water Pump .....	14-4
Waste (Black Water) Systems .....	14-4
Holding Tank .....	14-4
Waste Disposal Valve .....	14-5
Waste Disposal .....	14-6
Shore Disposal .....	14-6
Overboard Discharge .....	14-7

## Section 15: Heating, Ventilation, and Air Conditioning

Overview .....	15-1
Cabin Climate System .....	15-1
Power Source .....	15-1
HVAC Main Unit .....	15-2
Refrigerant .....	15-2
Air Filter .....	15-2
Condensate Drain .....	15-3
HVAC Raw Water System .....	15-3
Seacock .....	15-3
Strainer .....	15-3

HVAC Seawater Pump .....	15-3
Drainage .....	15-4
Ducting .....	15-4
Air Outlets .....	15-4
Ventilation .....	15-4
Mechanical Room Blower .....	15-4
Head Fan .....	15-4

## Section 16: Auxiliary Equipment

Bait Service Station .....	16
Livewell .....	16
Cockpit Sink .....	16
Fish Boxes .....	16

## Section 17: System Maintenance

Overview .....	17-1
Periodic Maintenance .....	17-1
Before Each Run .....	17-1
After Each Run .....	17-1
Periodic Maintenance .....	17-1
Safety Systems .....	17-3
Fire Suppression .....	17-4
CO Detector .....	17-4
Propane .....	17-4
Steel and Aluminum Systems .....	17-4
Maintenance .....	17-4
Bow Thruster .....	17-5
Visual Inspection .....	17-5
Electrical Connection Inspection .....	17-5
Inspect Bow Thruster Anode .....	17-5
Trim Tabs .....	17-5
Fuel Storage .....	17-5
Gasoline Storage .....	17-5
Diesel Storage .....	17-6
Diesel System Inspection .....	17-6
Fuel/Water Separator .....	17-6
Electrical Systems .....	17-6
Generator Maintenance .....	17-6
Bonding System .....	17-6
Battery Visual Inspection .....	17-7
Battery Voltage Check .....	17-7
GFCI Outlet Test .....	17-7
Fresh Water Systems .....	17-7
Water Tank Inspection .....	17-7
Manifold, Pump, and Line Inspection .....	17-8

Fresh Water Filter .....	17-8
Bilge and Sump Pumps .....	17-8
Bilge/Sump Pump Inspection.....	17-8
Bilge/Sump Pump Test .....	17-8
Anchor and Windlass .....	17-8
Visual Inspection .....	17-9
Lubrication .....	17-9
HVAC Systems .....	17-9
Blower Fan Inspection and Test .....	17-9
HVAC Unit Inspection .....	17-9
HVAC Raw Water System Inspection .....	17-9
Interior Maintenance .....	17-9
Wood Finishes .....	17-9
Countertops .....	17-10
Exterior Maintenance .....	17-10
Gelcoat Cleaning .....	17-10
Cleaning above Waterline .....	17-10
Cleaning below Waterline .....	17-11
Gelcoat Waxing .....	17-11
Finish Maintenance .....	17-11
Bottom Polishing .....	17-12
Stainless Steel Maintenance .....	17-13
Acrylic Mirrors and Windows .....	17-13
Aluminum .....	17-13
Polishing Copper .....	17-13
Seasonal Storage .....	17-14
Before Hoisting .....	17-14
Winterizing .....	17-14
Raw Water System .....	17-14
Drains .....	17-14
Raw Water System .....	17-15
Marine Toilet .....	17-15
Covering .....	17-15
Engines .....	17-15
Generator .....	17-15
Lifting and Keel Blocking .....	17-15
Recommissioning .....	17-17
Engines .....	17-17
Generator .....	17-17
Index .....	I-1